


Before use

1  Display warning signs.


2  Check equipment, especially plug and cable. Report any fault or damage to a supervisor.

3  Do not plug in and switch on at socket until machine is ready for use.

4  Tip machine back to put handle on floor and fit pad/pad drive or brush. Raise back upright.


5  Put the extra weight of 10 kg on the machine if necessary

During use

6  For wet scrubbing fill tank or mop cleaning solution on floor as appropriate.

7  Squeeze lower lever. Adjust handle position so operator's back is straight with arms slightly bent.


8  To activate machine hold locked handle so pad is flat to floor. Press orange safety button and squeeze upper lever.

9  Raise the handle upwards to go right and lower the handle to go left. Raise Right – Lower Left


10  Commence scrubbing at furthest point from plug socket. Work backward with cable behind you at all times.

11  old cable over handle, NOT over shoulder. Keep cable out of solution

12  Keep cable flat on the floor, NOT taut.


13  Cute in edges to avoid corrugated effect.

14  Work from side to side with overlapping passes.


15  Check pad/brush regularly for clogging. Unplug machine and turn/change pad as required.

After use

16  Put handle in upright position when not in use. Unplug if left unsupervised.

17  When changing socket, coil cable from machine to plug, not plug to machine, to avoid twisting.

18  Unplug.


19  Remove pad/pad drive or brush.

20  If solution tank fitted, check valve – clean as required.

21  Wind cable back into handle, wiping clean with a damp cloth as you do.

22  Wipe machine clean with a damp cloth.

23  Do not store machine with pad fitted.

24  Remove pad/pad drive or brush. Wash and hang to dry.

